


# Power Thyristor TS3 (SP) 1ph

# Installation Guide



#### **Contents:**

- 1. General Description
- 2. Installation of TS3 (SP) 1ph
- 3. Setting-up
- 4. Description of terminal connections
- 5. Description of LED's
- 6. Basic circuit
- 7. Overview of types
- 8. Technical Data

1



### 1. General Descriptions

Thyristors are more and more used where increased resistive and inductive loads have to be controlled. By means of the modular and compact construction as well as the control by a continuous action control signal, these Power Thyristors are becoming a perfect actuator for industrial power control.

The power unit of the Thyristor is made of two anti-parallel connected Thyristors, the insulated heat sink and the control electronics.

#### **Explanation of types:**

TS3 1ph A.C. Regulator with phase angle control for single-phase systems

TS3 SP 1ph A.C. Regulator with oscillation package single-phase systems

#### Construction:

The Thyristors correspond to the VDE 0558 Part 1 and VDE 0160 Table 4.

The Thyristor TS3 (SP) 1ph is integrated in a plastic housing (ABS). The main component of the Thyristor consist of the

**Power unit** with heat sink and the Thyristor wiring as well as of the **Control unit** with starter and control electronics.



## 2. Installation: Thyristor TS3 (SP) 1ph

A sufficient cooling (e.g. forced-air cooling) is of paramount importance. Temperature is not allowed to exceed 50°C. The device has to be mounted on a vertical area, so that a sufficient air circulation is guaranteed. Moreover, the Thyristor has to be installed in dry rooms.

#### Further on-site conditions:

- Protection against dust and humidity
- Protection against aggressive atmosphere
- Free of vibrations

In order to advoid any inferences of the cooling, no further components should be installed around the Thyristor within a distance from 50 to 100mm.

### Wiring:

Power supply (L1, N (L2) must be produced via a fail-save circuit breaker with the common backups.

The wiring for the power supply and the control unit must be done in separate channels or protection tube.

During the electrical installation procedure, the general VDE-regulations (VDE 0100, VDE 0113, VDE 160) must be observed, accordingly.



### 3. Set-up of Thyristor

First of all, all electrical connections should be set-up, according to the attached circuit diagrams: L1, N (L2), T1, T2.

According to the VDE-regulations, the Thyristors must be connected to the supply net in that way, that they can be separated from the net by means of corresponding clearing instruments (e.g. main switch, contactor, protective power-switch).

## Cabling:

The net and consumer lead wires as well as the control circuit must be lead in separate cables.

In order to avoid any interferences, it is advisable to wire the electronic signal lines separated from the load leads and/or the contactor control circuit and to twist the coming and going wires of the signal line.

#### Protection:

The net protection depends on the recommended respectively the used conductor cross section and must be made according to DIN 57100 Part 430/VDE 0100 Part 430/6.81.

#### General Information:

Thyristor TS3 for phase angle control is designed for the control of resistive and inductive loads. As a standard the control is made via the analog signal (0...10V or 0...20mA). The phase angle control respectively the on and off timing relation of the oscillation package control (pulse group operation) is continously corrected by the control electronics, in order to reach a sufficient proportionality between the Power Thyristor control and the output (T1, T2, T3).

T1 - T2



Load (heating resistance, motor, ...)

## 4. Terminal Connections

Clamps:	Functions:	Switch status:	Description of function:		
1 - 2	Start	closed opened	Soft start is activated Ready for operation		
3	Ureference	10V	To be used upon adjustment of potentiometer		
4	Ucontrol-Input	010V, 020mA, 2,510kΩ	Input for voltage and current signals or potentiometer adjustment (sliding contact)		
5	Earth		To be used upon current, voltage or potentiometer adjustment		
6 - 7	Interference relay output	Cl. 6,7 closed	Upon interference status		
8 - 9	Supply voltage (optional, not necessary)	230V/50 - 60Hz	For internal voltage supply (optional, not necessary)		
L1 -L2	Power supply	110V - 500V AC	Rating voltage		

## Control by voltage signal 0...10V:

Load connector

Switch (Ri) set to "0...10V" (Ri> $50k\Omega$ )

Clamp: 4 Signal input

5 Ground

# Control by current signal 0...20mA:

Switch (Ri) set to "0...20mA"

Clamp: 4 Signal input

5 Ground


# Control by potentiometer 2,5...10kΩ:

Switch (Ri) set to 0...10V'' (Ri> $50k\Omega$ )

Clamp: 3 Reference voltage 10V (supply voltage for potentiometer)

4 Sliding contact


5 Ground



Thermokon Sensortechnik GmbH Aarstraße 6 D-35756 Mittenaar Phone: +49 (0) 2772/6501-0 Fax: +49 (0) 2772/6501-400 email: email@thermokon.de Internet: www.thermokon.de



# 5. Description of LED's:



flashes if auxiliary voltage is fed

(Cl. 8+9)

flashes if Start (Cl. 1+2) is bridged

flashes if output voltage has reached 100%

flashes if thermal temperature of power unit is given. Switch-off at approx. 90°C.


# **Diagnosis Diagram**

Pos.	LED1	LED2	LED3	LED4	Funktionszustand	Fault-Relay Output (same time as LED 4)
1	green	*	*	*	Auxiliary voltage (Cl. 8+9) is fed; device ready for operation	
2	green	yellow	*	*	Device ready for operation; Start is activated (Cl. 1+2 bridged)	
3	green	yellow	yellow	*	Device ready for operation; Start is activated; ULoad is 100%	
4	green	*	*	red	Device ready for operation; An interference occurred	Cl. 6+7 closed
5	green	yellow	*	red	Device ready for operation; Start is activated; An interference occurred	Cl. 6+7 closed

<sup>\*</sup>no indication



# 6. Basic Circuit 1-phase





# 7. Overview of types


Туре	Maximal Load current	Recommended semi-conductor	Power protection	Recommended cross-section	Weight	Dimensions T x H x B
	[A]	protection[A]	[A]	[mm²]	[kg]	[mm]
TS3 (SP) 1ph 15A	15	25	25	2,5	1,1	92x125x90
TS3 (SP) 1ph 25A	25	30	32	4	1,1	92x125x90
TS3 (SP) 1ph 35A	35	40	50	6	1,1	92x125x90
TS3 (SP) 1ph 50A	50	60	80	10	1,1	92x125x90

<sup>\*</sup>Subject to errors and technical alterations

The maximum operation temperature amounts to 50°C.

The values mentioned are relating to a nominal operating voltage of 3x400V AC.

The values mentioned for the load are valid for an ambient temperature of 40°C and a mounting height of max. 1000m.





# 8. Technical Data

Туре:	TS3 (SP) 1ph 15A	TS3 (SP) 1ph 25A	TS3 (SP) 1ph 35A	TS3 (SP) 1ph 50A		
Power supply	230VAC					
Load current	15A	25A	35A	50A		
Supply voltage	Internal production					
Frequency	45Hz – 65Hz, self-synchronisation					
Inputs	010V, 020mA, Potentiometer connection: 2,510k $\Omega$ Switchable input impedance: 500 $\Omega$ , 50k $\Omega$					
Protection function	Thermal temperature switch-off by indication of LED: "Fault"					
LED-Display	Auxiliary Voltage (Hilfsspannung), Start, 100% Uload, Fault (Störung)					
Outputs	Fault message: Clamps 6, 7 closed, Load: 2A, 230V AC, AC1					
Power connection	L1 and L2 Input voltage; T1 and T2 Output voltage					
Control	Phase angle control respect. Oscillation control package (SP)					
Dissipation	1,1W per Ampere					
Ambient temperature	Operation: 0 to 45°C Storage: -10 to 70°C					
Air humidity	5% to 95% relative humidity, non-condensing					
Environment	Dry non-conductive environment					
Max. mounting height	1000m over NN					
Weight	1,1kg	1,1kg	1,1kg	1,1kg		
Protection	IP 40					
Dimensions	DxHxW = 92x125x90mm					
Mounting	on DIN-rail system (alternative mounting possibility with mounting plates)					
CE-sign	Accord. to European low-voltage directive 73/23/EEC and EMV directive 89/336 EWG for industrial applications					
*subjected to errors and tech	subjected to errors and technical alterations Issue: 25.07.2					

<sup>\*</sup>subjected to errors and technical alterations